



Instructions:

The mount is shipped assembled and ready to install. Along with an extra mirror base for left-hand thread applications. This mount system threads into either one of the unused mirror mount holes found on many metric handlebar control pods. Please follow the installation instructions carefully. If the un-used mirror mount locations have plastic plugs, these must be removed. The four (4) small holes in the top plate are the AMPs pattern found on many electronic accessories. The single ¼" (6mm) hole is used for mounting cameras with thumb screw mounting holes.

Step 1. Test fit the mirror base into the mirror mount hole to determine if it is standard (right-hand thread) or reverse (left-hand thread). Install the mount from the top with the correct base (**right-hand is marked with a dot at the treaded end**) into the unused mirror mounting hole in the handlebar control assembly and tighten firmly using a 19mm or ¾" open wrench.

Step 2. Adjust the pivot angle by adjusting the **Pivot Screw** and adjust the rotation as needed by adjusting the **Base Screw**. To remove the entire upper section of the mount. Remove the **Base Screw** and lift straight out.

Step 3. The mount has a rotating top plate that can be installed either of the two mounting holes in the top plate. This allows for more flexibility in offset mounting. Decide if the top plate is mounted in a suitable mounting hole. If not remove the **Top Plate Screw** that holds it in place and re-install as necessary. Make sure the small pin in the top plate locates into the counter rotation hole in the **Top Pin**. To rotate the top plate assembly, loosen the **Top Pin Screw** and rotate the top plate to the desired position.

Step 4. With the mount secure, now install the device onto the top plate.

Note: The maximum weight of your mounted device should not exceed 2 lbs. (1 k). Remember to snug all fasteners prior to riding.