# SENSORO SILVER BULLET RX7600




#### 1. Choose where to install the Silver Bullet radar detector

- Windshield installation to use with batteries (wirelessly) or with power cord.
- Dashboard and Visor installations work exclusively with the power cord.

#### 2. Install radar detector


#### Windshield - with Battery (use Bracket A)



- Install 2 AA alkaline batteries in the bracket battery box.
- Bend the bracket bars as needed to ensure the radar detector will be easily visible and level with the road.
- 3. Press securely against the windshield.
- Attach the radar detector to the bracket

   you will hear a "click" when properly connected.

#### Windshield - with Power Cord (use Bracket B)



- Bend the bracket bars as needed to ensure the radar detector will be easily visible and level with the road.
- 2. Press securely against the windshield.
- Attach the radar detector to the bracket – you will hear a "click" when properly connected.
- Plug the power cord into the radar detector and power socket of your vehicle.

Dashboard – with Power Cord (use Hook & Loop Fastener)



- Mount the radar detector directly onto the dashboard using the hook & loop fastener (with sticky sides attached to the dashboard and bottom of radar detector).
- Plug the power cord into the radar detector and power socket of your vehicle.

#### Visor - with Power Cord (use Visor Bracket)



VISOR BRACKET

- Clip visor bracket to the back, pivoting edge of your visor.
- Turn the radar detector upside-down and attach to the visor clip – you will hear a "click" when properly connected.
- 3. Attach the power cord to the radar detector.
- 4. Turn on the unit.
- Press and hold the MUTE and ALERT FILTER buttons simultaneously for 3 seconds to reverse the text display (so messages will be seen right-side-up).
- 6. Use the retaining clips to neatly tuck away the power cord.
- When you use bracket A or bracket B, make sure the suction cups pull-tabs are not positioned underneath the bracket, so they can be easily accessed for removal.

#### 3. Turn on the radar detector

- Move the POWER switch to ON.
- The screen will display "SENSORO RADAR DETECTOR \*\*\* FILTER-NORMAL" indicating a normal filter mode
- The screen will then display a random compass direction if the compass has not been set-up since purchase.
  - If you selected an alternate alert filter mode during previous use, it will display either "FILTER-HIGH" or "FILTER-OFF" instead of "FILTER-NORMAL" per your selection.

#### 4. Setting up the compass

- To set the compass readings you will need to drive your vehicle slowly in a full circle.
   Be sure you are in an area where you can safely perform this maneuver.
- Install the radar detector in your vehicle at your preferred location windshield, dashboard, or visor.
- 3. Press and hold the BACKLIGHT and MUTE buttons simultaneously for 3 seconds.
- 4. The screen will display "DRIVE IN A FULL CIRCLE... PRESS ANY BUTTON WHEN DONE."
- Drive your vehicle in a full circle. The direction and size of circle do not matter. You have one minute to complete the maneuver.
- 6. Press any button to complete the compass set-up.

#### 5. Receiving alert messages

- When a radar signal is detected, the screen displays the name of the band "X", "K", or "KA" – and a number indicating the strength of the signal (1 to 8).
- The higher the number, the stronger the signal.
- Stronger signals usually imply that you're closer to a police radar/laser device.
- When a laser signal is detected, the screen displays "LASER".

#### 6. Adjusting the Alert Filter

If you receive too many false alert signals, or are driving in specific environments, press the ALERT FILTER button to switch between filter modes:

- FILTER-NORMAL Optimized filtering for typical city or highway driving
- FILTER-HIGH Increased filtering to reduce most false alerts, good for high-density commercial areas
- FILTER-OFF No filtering of alert signals, ideal for open space areas

# For more information on how to get the most from your radar detector, see the Operation Manual.



## PNI Corporation

5464 Skylane Boulevard, Suite A • Santa Rosa, CA 95403 - USA 1-888-422-6672 • fax: 1-707-566-2261 www.pnicorp.com